


NEOI HDTV400 Quick Guide

1 At a Glance



2 Connection

NOTE! after Power up go to settings and **FIRST** select and connect to WiFi then set up a personal Google account and remove the factory side Google account!

1, Connect with TV

D01 HDMI Plug into HDMI TV.

If HDMI TV no enough space, pls. Use optional HDMI connector to connect.

Note! You may order the correct HDMI adapters from Neoi Shop!

2, Connect with power

Micro USB of A01 connect with USB Adapter (or you can directly connect with TV USB port) **Note!** TV needs to have HDMI Standard 1.4! USB at back side connect with USB receiver for 2.4G mouse

You also can use USB Hub to connect with more USB -device (don't support USB HDD)


USB Hub for SKYPE Video Camera and Audio as well Communicator free Neoi IP Phone calls

3, Network connection

A01 built in Wi-fi, press setup select Wireless & networks

1. Select Wi-Fi to turn on.

2. All the networks in range will be listed tap to select the network you would like to connect to.



3 Taskbar


Return	Home	Recent APPS	Volume down	Volume up	Android UI
Return	Return to last action				
Home	Back to Start Lajoin Home				
Recent APPS	View recent APPS and Fast enter				
Volume down	Volume down				
Volume up	Volume up				
Android UI	Android original Interface				

4 Remote Control

The Neoi HDTV 400 comes in standard version with a wireless mouse, which may control all functions via the mouse pointer on the TV screen.

Optional there are 2 IR/ Wireless Remote controls available, that allow a TV like remote control of teh system.

AR1 - Remote control with IR learning functions, allows basic functions of the Television to be learned into the HDTV 400 remote control



Neoi Air Mouse and programmable IR Smart TV / TV Remote Control

IR learning function and TV control are optional, requires AirMouse AR5

AR2 - a special GYRO remote control for fast Games and other Gyro related functions

optional accessory

Mobile Remote - Loading the Android Mobile QR code to an Android Mobile Phone or Tablet with Android 4.0 or higher will allow the complete control from the Mobile device. This includes then also the so called Picture /Video / Music throwing function. For details consult the special Manuals available from Neoi Technology Support.

Neoipad (Default UI) Controls



Setup for WiFi and Google accounts and other settings in Android

- Return to prior screen or application
- Neoipad Mode (Default) for Live TV and other Interactive NeoI APK. New APK will be pushed to screen from NeoI and may then require automatic update and installation.
- Screens (in Android Mode Only)
- Special Settings and functions for opened applications
- Volume + -
- Go to Android 4 APK and functions
- Soft Power Down ONLY use in case of Device RESET!
- Neoi Equalizer settings , MUST be installed for Audio thru Neoipad speakers
- WiFi Signal
- Signal for optional 3G Dongle connected via USB Hub

Copyrights, Digital Management licenses, AirPlay. Please be aware of the Copyrights for individual items. NeoI.tv , AirPlay, NeoIMarket, Communicator, NeoI UI, NeoIpad are all exclusive copyright protected Trademarks, Names, Functions and APK of NeoI Technology Pte. Ltd. Singapore, NeoI TEC Europe, NeoI TEC Germany, NeoI Tec Turkey, NeoI Tec India. Any violation of these licenses and copyrights will be followed by legal actions and heavy fines thru courts in related countries.

Contacts:
NeoI Technology Pte. Ltd. email: support@neoi.com.sg ; info@neoi-technology.com